


## Appendix to operating instructions OD22/2


### Position of operating and display elements



other Interfaces: see data sheet or sticker on lid

### Equivalent circuit diagram


... to calculate the data source resistor  $R_q$




View inside, scale 1:1

after adjustment

before adjustment



### Adjusting instructions in accordance with the light beam method



4713 HE (18.02.05 m)  
L 4713 28\_1 (16.03.05 m)  
(09.10.96 tb) (14.04.05 tb)  
(02.07.02 tb) 23.08.18 tb

1. Mount the transmitter and receiver in the desired locations.
2. If you are using our R27SH adjusting flange, set the adjusting springs to a preliminary tension of 16 mm.
3. Have a strong lamp to illuminate the lens system R of the B appliance held in the centre in front of the lens system T of the A appliance.
4. Use the JH2 adjusting aid to look into the lens system R; you will discern a circular section where the dark, square area of the light receiver is.
5. Bring the bright light spot visible inside the appliance (through the lamp

6. Then adjust the A appliance by illuminating the R lens of the A appliance with the lamp of the T lens of the B appliance and proceed as before.
7. The "DIANA" can then be used to optimise once the appliances are as far apart as possible.

The design and make of the devices and their electronics are intellectual property of the company "Fotoelektrik Pauly GmbH". Internal circuit diagrams can, for copyright reasons, not be given therefore. Subject to technical alterations. Errors excepted. The reprinting of this data sheet or the copying of extracts from it are allowed only with the approval of the "Fotoelektrik Pauly GmbH" and with an indication of the sources used. Infringements are punishable by law.